

QUARTZ CHESS CLOCK

SERVICE MANUAL

<u>C O N T E N T S</u>	<u>P A G E</u>
1. Specification	2
2. Circuit Description	3
3. Block Diagram	4
4. Schematic Diagram	5
5. PCB Track Diagram	6 - 9
6. Component Layout Diagram	10 - 12
7. Alignment Procedure	13 - 14
8. Functional Test Procedure	15 - 17
9. Trouble Shooting Chart	18
10. Part List	19 - 22

WRITTEN BY: M. P. FUNG
 DATE: 8th JULY, 1981

1. SPECIFICATION

A. Operating Voltage: 9V d.c. (6 pieces UM3 or AA size pen light batteries)

B. Current Consumption: 10MA Typical

C. Battery Life: 100 Hours Typical

D. Operating Temperature: 0°C to + 40°C

E. Storage Temperature: -20°C to + 70°C

F. Dimension: 111 mm (L) X 190 mm (W) X 38 mm (H)

G. Weight: 550 gm


2. CIRCUIT DESCRIPTION


The Quartz Chess Clock consists of essentially a TMS1100 micro-processor programme to provide time functions in accordance with the International Chess Rules. Precision timing is derived from a 32.768KHZ crystal controlled oscillator which feeds the TMS1100. Drive signals from the TMS1100 are converted by the Hughes LCD driver to drive the LCD display.


One half of an operational amplifier LM358 is used as a voltage regulator to supply a stabilised supply to the Hughes driver and the LCD display. The other half of the LM358 is used as a low battery comparater to provide low voltage indicator to indicate that change of batteries is necessary to maintain proper operation of the Clock.

A 6-pin phone jack is available to connect the Clock to other chess computers in the Novag line.


3. BLOCK DIAGRAM









REMOTE BUTTON PCB TRACK DIAGRAM




KEYBOARD PCB TRACK DIAGRAM




MAIN PCB TRACK DIAGRAM




DISPLAY BOARD PCB TRACK DIAGRAM



KEYBOARD JUMPER DIAGRAM



MAIN BOARD COMPONENT LAYOUT DIAGRAM



DISPLAY BOARD COMPONENT LAYOUT DIAGRAM

7. ALIGNMENT PROCEDURE

ALIGNMENT	EQUIPMENT REQUIRED	PROCEDURE
VOLTAGE	1. VARIABLE REGULATED DC SUPPLY. 2. HIGH INPUT IMPEDANCE VOLTMMETER OF AT LEAST 200K OHM/VOLT.	1. REMOVE BATTERIES FROM UNIT. 2. CONNECT POWER SUPPLY TO BATTERY TERMINALS AND SET IT TO 9.0V DC. 3. CONNECT VOLTMMETER TO PIN 7 OF LM358. 4. ADJUST VR1 (10K) UNTIL VOLTAGE AT PIN 7 OF LM358 IS -5.6V.
MICROPROCESSOR TMS1100 CLOCK ALIGNMENT	1. VARIABLE REGULATED DC SUPPLY. 2. HIGH INPUT IMPEDANCE FREQUENCY COUNTER.	1. REMOVE BATTERIES FROM UNIT. 2. CONNECT POWER SUPPLY TO BATTERY TERMINALS AND SET IT TO 9.0V DC. 3. CONNECT FREQUENCY COUNTER TO PIN 18 OF TMS1100. 4. ADJUST VR2 UNTIL THE CLOCK FREQUENCY IS 360 + 10KHZ.
LCD DRIVER CLOCK FREQUENCY VERIFICATION	1. VARIABLE REGULATED DC SUPPLY. 2. HIGH INPUT IMPEDANCE FREQUENCY COUNTER.	1. REMOVE BATTERIES FROM UNIT. 2. CONNECT POWER SUPPLY TO BATTERY TERMINALS AND SET IT TO 9.0V DC. 3. CONNECT FREQUENCY COUNTER TO PIN 6 OF 0607 DRIVER AND VERIFY THAT FREQUENCY IS 90 + 9HZ. 4. IF FREQUENCY IS INCORRECT, CHANGE R14 ACCORDINGLY.

ALIGNMENT	EQUIPMENT REQUIRED	PROCEDURE
EXTERNAL CLOCK	1. VARIABLE REGULATED DC SUPPLY. 2. HIGH INPUT IMPEDANCE FREQUENCY COUNTER	1. REMOVE BATTERIES FROM UNIT. 2. CONNECT POWER SUPPLY TO BATTERY TERMINALS AND SET IT TO 9.0V DC. 3. CONNECT FREQUENCY COUNTER TO 32.768 KHZ CRYSTAL AND VERIFY ITS FREQUENCY 4. IF FREQUENCY INCORRECT, CHANGE EITHER C3 OR C4.
LOW BATTERY INDICATION VERIFICATION	1. VARIABLE REGULATED DC SUPPLY.	1. REMOVE BATTERIES FROM UNIT. 2. CONNECT POWER SUPPLY TO BATTERY TERMINALS AND SET IT TO 9.0V DC. 3. REDUCE VOLTAGE AND OBSERVE WHETHER THE LOW VOLTAGE INDICATOR ON THE DISPLAY APPEAR WHEN VOLTAGE DROPS BELOW 7.5V DC. IF NOT, REPLACE ANY ONE OR MORE OF THE RESISTORS R5, R6, R7 & R8.

8. FUNCTIONAL TEST PROCEDURE

STEP	PROCEDURE	CORRECT OPERATION
1.	Switch on the unit by lifting the display housing.	1. Buzzer sounds 2. Display shows 5:00 5:00 ⓪ ◀1 ((⓪)) ⓪
2.	Press digit "5" five times.	1. Everytime key is depressed buzzer makes one blip. 2. Display shows: 5 55 55 ◀1 ((⓪))
3.	Press "SET TIME" key.	1. Buzzer blips. 2. Display shows: 5 : 55 : 55 : 0 ◀12 ((⓪))
4.	Press "4" & "0" keys.	1. Buzzer blips. 2. Display shows: 40 ◀1 ((⓪))
5.	Press "SET MOVE" key.	1. Buzzer blips. 2. Display shows: 40 99 # ◀12 ((⓪))
6.	Press "CLEAR" key.	1. Buzzer blips. 2. Display shows: 5 : 55 : 55 5 : 55 : 55 ⓪ ◀1 ((⓪)) ⓪
7.	Press "STRT/STP" Key.	1. Buzzer blips. 2. Left timer begins to counter down from 5:55:55

STEP	PROCEDURE	CORRECT OPERATION
8.	Press left remote button.	1. Buzzer blips. 2. ◀1 sign changes to 1▶ 3. Right timer begins to count down from 5:55:55.
9.	Press right remote button.	1. Buzzer blips. 2. Left timer will now count down from previous time.
10.	Press "MOVES LEFT" button.	1. Buzzer blips. 2. Display shows: 39 39 # ◀1 ((.)) 3. After several seconds, display reverts to show time.
11.	Press "ET/MOVES" key.	1. Buzzer blips. 2. Display shows: 1 0:01 # ◀1 ((.)) ①+① (Note: The last digit 1 may be 1, 0, 2 or any number depending on how long the proceeding operation has taken. It shows the clapsed time in hours and minutes.
12.	Press "1" key five times.	1. Buzzer blips five times. 2. Display shows: 1 11 11 ◀1 ((.))
13.	Press "ADD WHITE" key.	1. Buzzer blips. 2. White's time is increased by 1 hr. 11 minutes, and 11 sec.
14.	Press "ADD BLACK" key.	1. Buzzer blips. 2. Black's time is increased by 1 hr 11 minutes and 11 sec.

STEP	PROCEDURE	CORRECT OPERATION
15.	Press "RESET" key.	1. Buzzer blips. 2. Both white and black time reverts to 5:55:55. Also there is no count down.
16.	Press 'SOUND' key.	1. ((•)) sign disappears. 2. Pressing any other key or remote button will not produce a blip.

<u>PROBLEMS</u>	<u>POSSIBLE CAUSES</u>
Unit Dead	1. Battery voltage too low. 2. Battery connecting wires broken. 3. Push button on/off switch defective.
No Sound (Except when unit is turn off and then on again within five seconds)	1. Buzzer defective. 2. Connection to buzzer broken. 3. Defective microprocessor.
Display Segment or Symbol missing	1. Defective display. 2. Defect zebra connector. 3. Broken track. 4. Defective microprocessor or driver.
Remote Control no function	1. Connecting wire broken. 2. Open circuit track. 3. Defective microprocessor.
Key or Keys no function	1. Defective microprocessor. 2. Defective rubber conductor. 3. Open circuit track.
Low battery indicator wrong indication	1. Incorrect low battery indication circuit component. 2. Defective op. amplifier.
Inaccurate Timing	32.768 KHz crystal oscillator circuit defective.

PART LIST

<u>ITEM</u>	<u>DESCRIPTION</u>	<u>PART NO.</u>	<u>QTY</u>	<u>UNIT COST</u> US\$
1	LOGIC PCB SINGLE SIDE	1P6269	1	0.50
2	DISPLAY PCB SINGLE SIDE	1P6301	1	0.70
3	K.B. PCB SINGLE SIDE	1P6311	1	0.40
4	REMOTE PCB SINGLE	1P6320	2	0.20
5	MICROPROCESSOR TMS1100	1V2650	1	4.50
6	QUAD-NAND SCHMIDT CD4093	1V2651	1	0.45
7	12-STAGE COUNTER CD4040	1V2652	1	0.65
8	DUAL OP-AMP LM358	1V2641	1	0.56
9	LCD DRIVER 0607	1V2653	1	4.00
10	LCD CLOCK DISPLAY TP5802	1V4370	1	8.00
11	PNP G.P. TRANS. 2N2907	3M3190	1	0.20
12	SWITCHING DIODE 1N4148	3M1051	3	0.05
13	SILICON RECTIFIER 1N4001	3M1030	2	0.10
14	ZENER DIODE 3.3V 5%	3M1490	1	0.15
15	32.768KHZ CRYSTAL	3K0080	1	0.80
	<u>RESISTORS 5% 1/4W</u>			
16	470 OHM	3R0431	2	0.01
17	25 KOHM	3R0791	1	0.01
18	6.8 KOHM	3R0681	1	0.01
19	10 KOHM	3R0711	4	0.01
20	15 KOHM	3R0741	1	0.01
21	47 KOHM	3R0381	1	0.01
22	330 KOHM	3R0411	1	0.01
23	2.7 MOHM	3R1191	1	0.01
24	100 KOHM	3R0951	1	0.01

ITEM	DESCRIPTION	PART NO.	QTY	UNIT COST US\$
	<u>RESISTORS 1% 1/4W</u>			
25	10 KOHM	3R0713	3	0.04
26	17 KOHM	3R1163	1	0.04
27	1.5 MOHM	3R1162	1	0.04
28	TRIMMER RES. 10 KOHM	3R2145	2	0.20
	<u>CAPACITORS</u>			
29	ELECT. 2.2UF/16V	3E0052	2	0.05
30	CER. 10% 25PF/50V	3C0182	2	0.05
31	CER. 10% 100PF/50V	3C0362	1	0.05
32	CER. 10% 0.1UF/25V	3C0684	1	0.05
33	MYL. 5% 0.01UF/25V	3C1246	1	0.05
34	ELECT. 100UF/16V	3E0142	1	0.05
35	CER. 0.02UF/16V	3C0654	1	0.05
36	6-PIN CONN. RT ANGLE	4T7340	1	0.25
37	6-PIN CONN. STRT	4T7330	1	0.25
38	13-PIN CONN. ARRAY	4T7210	1	0.10
39	COND. RUBBER (K.B.)	4T3441	1	0.40
40	COND. RUBBER (REMOTE)	4D3450	2	0.10
41	6-POS'N FLEX CABLE	4T7170	1	0.20
42	REMOTE CONTROL CABLE	3W2131	2	0.10
43	6-PIN PHONE SOCKET	2J0210	1	1.00
44	27mm TRANSDUCER	3K0050	1	0.25
45	STTRADED WIRES	-	A/R	-
46	DISPLAY HOUSING TOP	4D3330	1	0.55
47	DISPLAY HOUSING BOTTOM	4D3340	1	0.55
48	K.B. HOUSING TOP	4D3361	1	0.30
49	K.B. HOUSING BOTTOM	4D3351	1	0.30
50	REMOTE SW. HOUSING TOP	4D3390	2	0.10

<u>ITEM</u>	<u>DESCRIPTION</u>	<u>PART NO.</u>	<u>QTY</u>	<u>UNIT COST</u> <u>US\$</u>
51	REMOTE SW. HOUSING BOTTOM	4D3400	2	0.10
52	KEYTOPS	4D3320	20	0.02
53	BATTERY DOOR	4D3370	1	0.10
54	LCD COVER (MOUNT)	4D3380	1	0.30
55	REMOTE SW. BUTTON	4T7130	2	0.20
56	AL. DISPLAY INLAY #1	7X077	1	0.10
57	AL. DISPLAY INLAY #2	7X078	1	0.25
58	DISPLAY PVC INLAY	7X080	1	0.15
59	K.B. FUNCTION PLATE	7X079-1	1	0.15
60	BATTERY CONTACT 1P	4T7140	1	0.10
61	BATTERY CONTACT 1P	4T7141	1	0.10
62	BATTERY CONTACT 2P	4T7150	1	0.20
63	NI. PLATED HINGES	4T7160	2 SETS	0.20
64	BATTERY LABEL	7J766	1	0.02
65	WOOD GRAIN PAPER	4F1290	1	0.05
66	RUBBER SHEET	4D3460	2	0.05
67	RUBBER FEET	4D3280	4	0.01
68	SPACER	4D3410	1	0.02
69	SCREWS	-	A/R	-
70	WASHER	-	A/R	-
71	POLYFOAM	7F098	1 SET	0.30
72	POLYBAG	6G1050	1	0.05
73	TEL. CABLE W/PLUG	3W2121	1	1.60
74	MANUAL	7G779	1	0.30
75	WARRANTY CARD	7G778	1	0.05
76	GIFT BOX	7B625	1	0.60
77	PAPER LABEL	-	1	0.02
78	SHIPPING CARTON	7T324	1/12	1.20