

PRESIDENT



SaitekTM

Doc. No. : SW19-PG-35

Rev. : 0.1

Date : 5.7.93

SW19 GENERAL PRODUCT SPECIFICATIONS

- A. Battery Requirement : 1.5V (size 'C' or 'UM-2') X 6 pcs.
Alkaline type recommended
- B. Operating Voltage : 6.6 - 10.2 Volts
- C. Adaptor Operating Voltage : 8 - 12 volts
- D. Current Consumption : a) Normal mode at V₉₀ = 9V
with two LEDs on
35mA typical
61mA max
b) Memory mode at V₉₀ = 9V
100uA typical
300uA max
- E. Power Consumption : 315mW typical
550mW max
- F. System Clock Frequency : 20MHz +/-5% (AT V₉₀ = 9V)


PREPARED BY : Tan
C. W. Tang

APPROVED BY : [Signature]

DIST : QAM, IEU, SEE, SEA

FILENAME : \ED#01\SW19

ORIGINAL



PROJECT : PRESIDENT CHESS
DOC. NO. : SW19-PS-35
REV. : 0
DATE : 2.7.93

ADJUSTMENT PROCEDURE FOR SW19


OBJECT : To adjust system clock frequency.

EQUIPMENT NEEDED : Frequency counter or Oscilloscope capable of frequency measurement up to 20 MHz.


PROCEDURE :

1. Disassemble unit by removing screws (8) on cabinet base.
2. Power on unit (V90 = 9V)
3. Place probe of counter/scope at pin 9 of U1.
If frequency measured is out of specified range (19 - 21MHz), replace C4 or C3 (S.O.T.) until counter/scope reading is within specification.
4. Reassemble unit.

PREPARED BY :


C. W. Tang

APPROVED BY :



DIST : QAM, IEM, SEE, SEA

FILENAME : \ED401\SW19

PROJECT : SW19
 DOC. NO. : SW19-PS-040
 REV. : 0
 DATE : 28.12.93
 C.C. : QA, ED

SW19 TROUBLE SHOOTING CHART


SYMPTOMS		POSSIBLE CAUSES
1. Unit will not turn on	i) ii) iii)	Check Vcc for 6.6V to 10.2V: If Vcc is not within this range: 1. Dead or weak battery 2. Broken connection in battery wiring 3. Defective adapter - Check adapter voltage under load 4. Broken connection between adapter socket and logic PCB 5. Defective voltage regulator - Check D1,D2,D3,D4,Z1,R1,U2 Check clock circuit - Look for 20 MHz oscillation at U1 pin 10/9. If not, 1. Check X1 2. Defective U1 Check reset circuit: - Check action at U1 pin 8 from logic "LOW" to logic "HIGH" after "ACL" is pressed. If not, - Check D5,R2,C2,contact on ACL
2. LED (s) turn on when they should not	i) ii) iii) iv) v) vi)	Look for broken traces or short circuits on PCBs Broken connections between PCBs Defective corresponding LED Defective corresponding resistor Defective U1 Check Q1-Q8,R9-R32
3.No response or improper* response to command keys	i) ii) iii)	Check no dust,oxide,opened circuit in golden finger Loose contacts or misalignment between sensor and PCB traces Defective U1
4. No sound	i) ii) iii) iv)	Broken wiring from beeper to PCB Defective beeper Defective D6,D7 Defective U1, Check for pulse output at U1 pin 29 when "SOUND ON"
5. No Go/Stop function	i) ii) iii)	Check connections between switch and PCB Broken or short circuits on PCB Check R4

Daniel

	iv)	Check pin 5 logic "Low" when GO/STOP pressed on.
	v)	Defective U1
6. Excessive current drain Current > 61mA when "GO" Current > 300µA in "STOP"	i)	Components wiring or PCB trace short-circuited
	ii)	Contaminations and/or foreign particles on PCB
	iii)	Capacitor leakage- Check C1,C5
	iv)	Defective U2
7. Generates illegal moves when escapes from "STOP"	i)	Battery exhausted
	ii)	Defective U1



FILE : ED#10A/SW19PS40

Daniel M. [Signature]



SHEET		OF		BOD VBB'D		MATERIAL		FINISH	
ORIGINAL :		GFC VBB'D		2/1/10		B.V. :			
SCALE : 1 : 1		ENERG VBB'D		3/2/03		DWC NO :		2M14-BE-01557	
DWC :		CHECK BY :		3/4/03		DATE :		28/08/03	
TOLERANCES		DRAWN BY :		P.H.B		DESCRIPTION OF CHANGE		APPROVED :	
3RD VNGLE PROTECTION		SIGNATURE		DATE		REV ITEM		ED BY EDC	
						1		2	
						2		3	
						3		4	
						4		5	
						5		6	
						6		7	
						7		8	
						8		9	
						9		10	
						10		11	
						11		12	
						12		13	
						13		14	
						14		15	
						15		16	
						16		17	
						17		18	
						18		19	
						19		20	
						20		21	
						21		22	
						22		23	
						23		24	
						24		25	
						25		26	
						26		27	
						27		28	
						28		29	
						29		30	
						30		31	
						31		32	
						32		33	
						33		34	
						34		35	
						35		36	
						36		37	
						37		38	
						38		39	
						39		40	
						40		41	
						41		42	
						42		43	
						43		44	
						44		45	
						45		46	
						46		47	
						47		48	
						48		49	
						49		50	
						50		51	
						51		52	
						52		53	
						53		54	
						54		55	
						55		56	
						56		57	
						57		58	
						58		59	
						59		60	
						60		61	
						61		62	
						62		63	
						63		64	
						64		65	
						65		66	
						66		67	
						67		68	
						68		69	
						69		70	
						70		71	
						71		72	
						72		73	
						73		74	
						74		75	
						75		76	
						76		77	
						77		78	
						78		79	
						79		80	
						80		81	
						81		82	
						82		83	
						83		84	
						84		85	
						85		86	
						86		87	
						87		88	
						88		89	
						89		90	
						90		91	
						91		92	
						92		93	
						93		94	
						94		95	
						95		96	
						96		97	
						97		98	
						98		99	
						99		100	


REDUCED TO 50.0 MM



REV.1

SW19-PE-013


P/N 512990-01321




correct a diode circuit 26/7/74
20.7.74
Zang
Saitek


3RD ANGLE PROJECTION	SIGNATURE	DATE	REV	ITEM	WAS	IS	DESCRIPTION OF CHANGE	DATE DRAWN	CHECK	ED	QA	BDD	APPROVED
TOLERANCES	DRAWN BY: TY	24/1/93											
DIM. :	ANGLE:	23/5/93											
SCALE: 1	UNIT: mm	23/5/93											
QUANTITY :	Q.A. APPD.	23/5/93											
SHEET OF	BDD APPD.	23/5/93											


TITLE: Chessboard (8) Layout
- Solder Side -
PROJECT: SW19
DWG. NO.: SW19-PE-01355
P.N.: 15.1.2.9.9.0-01321
MATERIAL: FINISH





3RD ANGLE PROJECTION		SIGNATURE		DATE	REV. ITEM	DESCRIPTION	DATE	DRAWN	CHECKED	BY	DATE	APPROVED
TOLERANCES		DRAWN BY: TY		25.5.99								
DIM. : ANGLE:		CHECK BY: [Signature]		25.5.99	1	Saitek						
SCALE: 1:2		UNIT: mm		ENGRG AUTH: [Signature]	25.5.99							
QUANTITY:		Q.A. APPD. [Signature]		25.5.99								
SHEET OF		3RD APPD. [Signature]		25.5.99								

[illegible]



SW19-PE-005 REV. 1
P/N 512990-00541

REDUCED TO 114.0 MM


CLEAR PIECE ENTER


LEVEL

POSITION

OPTION


INFO





ORIGINAL

REVISION		ECN REV.
DATE	DESCRIPTION	NO.



APPROVALS	DATE	
E.E. <i>[Signature]</i>	2/14/93	
DRAWN CHENG	2/11/93	
E.D. <i>[Signature]</i>	4/11/93	
B.D.D. <i>[Signature]</i>	8/11/93	
Q.A. <i>[Signature]</i>	4/11/93	

Saitek Ltd.	
SCHEMATIC DIAGRAM	
TITLE: 299	PRESIDENT CHESS
DWG. NO. SW19 - PE - 010	REV. 0

SAITEK

BILL OF MATERIALS

PROJECT : SW19 (PRESIDENT CHESS)

ART.NO. : 299

SHIP VER. : EV

REVISION : 3.02

FILENAME : \ED#P01\SW19

REVISION HISTORY

<u>REVISION</u>	<u>DATE</u>	<u>BY</u>	<u>DESCRIPTION OF CHANGES</u>
P1	28.05.93	C.W. TANG	Preliminary BOM.
P2	07.06.93	C.W. TANG	Preliminary BOM.
1	28.06.93	C.W. TANG	Parts up-date.
1.1	06.07.93	C.W. TANG	Parts up-date.
2	23.09.93	ANGUS SAM	Parts up-date (ECN#93086)
3	24.09.93	ANGUS SAM	Adjust ALC (Ref.:SE-Price of ALC & Block Charge Rev.1)
3.01	02.02.94	ANGUS SAM	Updated ALC.
3.02	09.02.94	ANGUS SAM	Chessmen, Pawn (P/N 234200-07600) cost amended, Option assembly updated.

RELATED DOCUMENTSREV

Schematic dwg : SW19-PE-010

0

Prepared BY : Angus 9-2-94
ANGUS SAMApproved by : AKRES EM

18-2-94

Distribution :

+1.00 [] MMM, IEM FAM; QAM, SEE

+0.10 [] MMM, IEM FAM; QAM, SEE

+0.01 [X] MMM, IEM

Circulate : MSM-> GM-> BDM2 -> BDM1

Date issue : 18 FEB 1994

CHG MOD: NW=new component; * =desc/PN/Ref changed +/-=cost up/down; C/NC=consigned/non-consigned +/-Q=QTY up/down

992990-11EV

- SW19, EV, PRESIDENT CHESS

Rev : 3

Level	Item	Chg	Stock Code	Rev	Cons	Description	Qty	Per Reference
1			982990-00000	1		UNIT ASSEMBLY, FOR SW19	1.000	
2			912990-00001	1		GUTS ASSEMBLY-LOGIC	1.000	
3	1		512990-01411			PCB, LOGIC, SS, 1.6MM PAPER PHENOLIC	1.000	
3	2		860961-51A08	RC		MICROPROCESSOR, SW19, DIP	1.000	U1
3	3		741413-00042	RC		TTL, -42, BCD TO DECIMAL DECODER, HC	1.000	U3
3	4		522080-00320	RC		SWITCH, 1P1T, FOR ST11E, JTM-1105C	1.000	ACL
3	5		690014-00000	RC		ELECT REGULATOR, 5V RESRAS0AC	1.000	U2
3	6		654148-10000			DIODE, SWITCHING, 1N4148	4.000	D1, 5-7
3	7		654001-20000			DIODE, RECTIFIER, 1N4001	3.000	D2-4
3	8		613905-41102			RESISTOR, FIXED, C-FILM, 39, 5%, 1/2W	1.000	R1
3	9		617535-31102			RESISTOR, FIXED C-FILM, 75K, 5%, 1/4W	1.000	R2
3	10		611035-31102			RESISTOR, FIXED C-FILM, 10K, 5%, 1/4W	5.000	R3, 9-10, 12-13
3	11		611035-31102			RESISTOR, FIXED C-FILM, 10K, 5%, 1/4W	5.000	R15-16, 18-19, 21
3	12		611035-31102			RESISTOR, FIXED C-FILM, 10K, 5%, 1/4W	5.000	R22, 24-25, 27-28
3	13		611035-31102			RESISTOR, FIXED C-FILM, 10K, 5%, 1/4W	2.000	R30-31
3	14		612245-31102			RESISTOR, FIXED C-FILM, 220K, 5%, 1/4W	1.000	R4
3	15		613335-31102			RESISTOR, FIXED, C-FILM, 33K, 5%, 1/4W	4.000	R5-8
3	16		613915-31102			RESISTOR, FIXED C-FILM, 390, 5%, 1/4W	5.000	R11, 14, 17, 20, 23
3	17		613915-31102			RESISTOR, FIXED C-FILM, 390, 5%, 1/4W	3.000	R26, 29, 32
3	18		611535-32109	RC		RESISTOR, ARRAY C-FILM, 15KX8, 5%, 1/4W, 9	1.000	R33-40
3	19		670290-12690	RC		TRANSISTOR, PHP, 9012G, CENTRE B	8.000	Q1-8
3	20		621047-01611			CAPACITOR, C-CAP, 0.1UF, +80-20%, 16V	1.000	C5
3	21		622267-01615			CAPACITOR, E-CAP, 2.2UF, +80-20%, 16V	1.000	C6
3	22		642000-03250	RC		RESONATOR, 20MHZ, 50PPM	1.000	X1
3	23		622267-01615			CAPACITOR, E-CAP, 22UF, +80-20%, 16V	1.000	C1
3	24		650000-31005			DIODE, ZENER, 10V, +/-5%, 1/2W	1.000	Z1
3	25		622267-01616			CAPACITOR, E-CAP, 2.2UF, +80-20%, 16V, L.L.	1.000	C2
3	26		62150J-05014			CAPACITOR, C-CAP, NPO, 15PF, +/-5%, 50V	2.000	C3, 4
3	27		000190-00019			CONNECTOR, EDGE, 36 PIN	1.000	
3	28		000030-01170			CONN ARRAY, N=12, L=310MM, P=2MM, E=3.5MM	2.000	
3	29		000050-80155			JUMPER, L=8MM, LL=15MM, D=0.5MM	5.000	J18-20, 22-23
3	30		000050-80155			JUMPER, L=8MM, LL=15MM, D=0.5MM	12.000	J25-32, 12-15
3	31		000051-20155			JUMPER, L=12MM, LL=15MM, D=0.5MM	12.000	J1-3, 5-11, 16-17
3	32		000051-20155			JUMPER, L=12MM, LL=15MM, D=0.5MM	1.000	J24
3	33		000051-50155			JUMPER, L=15MM, LL=15MM, D=0.5MM	1.000	J4
2			912990-00002	1		GUTS ASSEMBLY-LED "A"	1.000	
3	34		512990-01220			PCB, LED "A", 1.6MM, PAPER PHENOLIC	1.000	
3	35		660009-11002	RC		LED, RED, FLAT HEAD, D=2MM, TOSHIBA TLR206	32.000	LED A1-D8
3	36		525110-00110	RC		SWITCH, REED, FOR SW6.1, ORD225	32.000	RS A1-D8
3	37		654148-10000			DIODE, SWITCHING, 1N4148	32.000	D11-42
3	38		000030-01180			CONN ARRAY, N=10, L=40MM, P=2MM, E=3.5MM	2.000	
3	39		000050-80155			JUMPER, L=8MM, LL=15MM, D=0.5MM	28.000	
2			912990-00012	1		GUTS ASSEMBLY-LED "B"	1.000	
3	40		512990-01321			PCB, LED, "B", S.S., 1.6MM, PAPER PHENOLIC	1.000	
3	41		660009-11002	RC		LED, RED, FLAT HEAD, D=2MM, TOSHIBA TLR206	32.000	LED E1-H8
3	42		525110-00110	RC		SWITCH, REED, FOR SW6.1, ORD225	32.000	RS E1-H8
3	43		654148-10000			DIODE, SWITCHING, 1N4148	32.000	D43-74
3	44		000050-80155			JUMPER, L=8MM, LL=15MM, D=0.5MM	23.000	

992990-11EV

- SW19, EV, PRESIDENT CHESS

Rev : 3

Level	Item	Chg	Stock Code	Rev	Cons	Description	Qty Per Reference
3	45		000051-20155			JUMPER, L=12MM, LL=15MM, D=0.5MM	10.000
2			912990-00000	1		GUTS ASSEMBLY-LCD & K-BOARD, CONTROL	1.000
3	46		512990-00541			PCB, LCD & K BOARD, DS.1.6MM, FR4	1.000
3	47		654148-10000			DIODE, SWITCHING, 1N4148	10.000 D75-84
2			962990-00000	1		CASING ASSEMBY FOR SW19	1.000
3	48		000073-11454			SCREW, S/T, +BIND, M2.6X12MM, A	8.000 B-CAB & CHESSBD
3	49		000073-21534			SCREW, S/T, +PAN, M3.0X8MM, A	6.000 FOR LOGIC PCB
3	50		000073-11434			SCREW, S/T, +BIND, M2.6X8MM, A	1.000 B-CAB> CONTROL
3	51		000073-11534			SCREW, S/T, +BIND, M3X8MM, A	10.000 FOR REED PCB
3	52		222700-03500		RC	METAL, B-CONT, COM, PH BRONZE, NI-PLT, ST5	1.000
3	53		224200-03100		RC	METAL, B-CONT, COM 'B', PH BRONZE, NI-PLT, W1	1.000
3	54		227020-03400		RC	METAL, B-CONT, "+", PH BRONZE, NI-PLATED, DG4	1.000
3	55		227020-03500		RC	METAL, B-CONT, "-", PH BRONZE, NI-PLATED, DG4	1.000
3	56		000130-00270			BUIZZER, D=27MM	1.000
3	57		000220-00002			SOCKET, DC POWER JACK, TC 18-014	1.000
3	58		000107-06503			SPONGE, 70X65X3MM	1.000
3	59		000090-00400			FOAM PAD, 16X7.8X2MM, ADHESIVE	1.000 FIX GO/STOP KEY
3	60		352990-02300		RC	INLAY, FOR JACK, PVC, BLK, SW19	1.000
3	61		352990-05201		RC	INLAY, FOR GO/STOP, PVC, BLK, SW19	1.000 FOR GO/STOP
3	62		292990-02200		RC	CONTROLLER INLET COVER, PVC, ADHESIVE	1.000
3	63		000060-08043			STRAND WIRE, BLACK, L=80MM, E=3.5MM, AWG28	1.000 +
3	64		000062-09043			STRAND WIRE, RED, L=90MM, E=3.5MM, AWG28	1.000 -
3	65		000065-08043			STRAND WIRE, GREEN, L=80MM, E=3.5MM, AWG28	1.000 G
3	66		000060-30043			STRAND WIRE, BLACK, L=300MM, E=3.5MM, AWG28	1.000
3	67		000062-37043			STRAND WIRE RED, E=3.5MM, L=370MM, AWG28	1.000
3	68		000064-08041			STRAND WIRE, YELLOW, L=80MM, E=3.5MM, AWG30	2.000 FOR GO/STOP KEY
3	69		000068-15043			STRAND WIRE, GREY, L=150MM, E=3.5MM, AWG28	2.000 BUIZZER
3	70		000021-00010			RUBBER FOOT, 3M, D12X3.2MM, ADHESIVE	4.000 CHESSBOARD
3	71		522990-00410			SWITCH, PUSH FOR SW19, PIC-PB-11901	1.000 GO/STOP
3			952990-00000	1		CABINET SET, CHESSBOARD, SW19	1.000
4	72		214210-00205		RC	PLASTIC, CHESSBOARD B-CAB, HIPS, BLK	1.000
4	73		232990-00100		RC	WOOD, CHESSBOARD CABINET, M.D.F., TEAK	1.000
4	74		214210-00300		RC	PLASTIC, BATT.LID, HIPS, BLACK	1.000
4	75		214210-00400		RC	PLASTIC, EPROM COVER, HIPS, BLACK	1.000
3			922990-00000	1		MODULE, CONTROL, CASING AND ASSEMBLY, SW19	1.000
4	76		532820-00290		RC	LCD, FOR ST12	1.000
4	77		250000-00529		RC	ZEBRA CONNECTOR, SG, 46+2.3+12.3, P=.18MM	1.000
4	78		000090-00800			FOAM PAD, SW19	1.000 LCD
4	79		256880-00910		RC	RUBBER, CONDUCTIVE KEYPAD 'B', FOR SW19	2.000 IN, OPT, PO, LE, EN
4	80		256880-01010		RC	RUBBER, CONDUCTIVE KEYPAD 'C', FOR SW19	1.000 BK, WT, CLR, P TYP
4	81		000073-11434			SCREW, S/T, +BIND, M2.6X8MM, A	7.000
4	82		000073-21234			SCREW, S/T, +PAN, M2.3X8MM, A	5.000 FOR CONTROL
4	83		342990-02000		RC	NAME PLATE, AL SHEET, KASPAROV, SCR'N	1.000
4	84		000021-00020			RUBBER FOOT, 3M, D6.5X3.2MM, ADHESIVE	4.000
4			952990-00010	1		CABINET SET, CONTROL MODULE, SW19	1.000
5	85		212990-00201		RC	PLASTIC, CONTROL MODULE, T-CAB, HIPS, BLK	1.000

992990-11EV

- SW19, EV, PRESIDENT CH135

Rev : 3

Level	Item	Chg	Stock	Code	Rev	Cons	Description	Qty	Per Reference
	5	86	242990-00341		RC		PLASTIC, CONTROL MODULE, 2-CAS, HIP, BLK	1.000	
1			942990-10700	1			PACKING ASSEMBLY, FOR SW19	1.000	
2	87		442990-01100				CARTON, FOR SW19, 4PC/CTN	.250	
2	88		452990-01400				INSERT 1, UNIT & MODULE, SW19	1.000	
2	89		452990-02540				INSERT, UNIT, SW19	1.000	
1	90		000125-00700				POLYBAG, 500X500X0.045MM	1.000	UNIT
2	91		000122-15140				POLYBAG, 215X140X0.045MM	1.000	MODULE
2	92		000123-00100				POLYBAG, 300X200X0.045MM	1.000	MANUAL
2	93		370000-00100	RC			LABEL, COMMON, CUSTOMER LABELS	1.000	
2	94		340000-00100				LABEL, FOR SERIAL NO, ADHESIVE	1.000	
2	95		462910-10500	RC			ACCESSORY, POUCH, FOR SA9 CHESSMEN	1.000	
2			242990-19400	1			CHESSMEN SET, SW19 2-5/8", BLITZ	1.000	
3			242990-19510	1			CHESSMEN SUBSET, SW19, 2-5/8", BLITZ, BROWN	1.000	
4			244200-08401	1			CHESSMEN, SW19, KING, BROWN, D13X4, BLITZ	1.000	
5	96		234200-07110	RC			WOOD, KING, D. BROWN, W/O MAG, W1	1.000	
5	97		000161-00150	RC			MAGNET, 150, FERRITE, D13X4	1.000	
5	98		295100-08210	RC			FELT, DIA 20MM, BLK, W ADHESIVE	1.000	
4			244200-08401	1			CHESSMEN, SW19, QUEEN, BROWN, D13X4, BLITZ	1.000	
5	99		234200-07210	RC			WOOD, QUEEN, D. BROWN, W/O MAG, W1	1.000	
5	100		000161-00150	RC			MAGNET, 150, FERRITE, D13X4	1.000	
5	101		295100-08210	RC			FELT, DIA 20MM, BLK, W ADHESIVE	1.000	
4			244200-08481	1			CHESSMEN, SW19, BISHOP, BROWN, D13X4, BLITZ	2.000	
5	102		234200-07310	RC			WOOD, BISHOP, D. BROWN, W/O MAG, W1	1.000	
5	103		000161-00150	RC			MAGNET, 150, FERRITE, D13X4	1.000	
5	104		295100-08210	RC			FELT, DIA 20MM, BLK, W ADHESIVE	1.000	
4			244200-08401	1			CHESSMEN, SW19, KNIGHT, BROWN, D13X4, BLITZ	2.000	
5	105		234200-07410	RC			WOOD, KNIGHT, D. BROWN, W/O MAG, W1	1.000	
5	106		000161-00150	RC			MAGNET, 150, FERRITE, D13X4	1.000	
5	107		295100-08210	RC			FELT, DIA 20MM, BLK, W ADHESIVE	1.000	
4			244200-08481	1			CHESSMEN, SW19, ROOK, BROWN, D13X4, BLITZ	2.000	
5	108		234200-07510	RC			WOOD, ROOK, D. BROWN, W/O MAG, W1	1.000	
5	109		000161-00150	RC			MAGNET, 150, FERRITE, D13X4	1.000	
5	110		295100-08210	RC			FELT, DIA 20MM, BLK, W ADHESIVE	1.000	
4			244200-08471	1			CHESSMEN, SW19, PAWN, BROWN, D13X4, BLITZ	8.000	
5	111		234200-07610	RC			WOOD, PAWN, D. BROWN, W/O MAG, W1	1.000	
5	112		000161-00150	RC			MAGNET, 150, FERRITE, D13X4	1.000	
5	113		294200-08510	RC			FELT, DIA 17 MM, BLK, W ADHESIVE	1.000	
3			242990-19510	1			CHESSMEN SUBSET, SW19, 2-5/8", BLITZ, BEIGE	1.000	
4			244200-09001	1			CHESSMEN, SW19, KING, BEIGE, D13X4, BLITZ	1.000	
5	114		234200-07100	RC			WOOD, KING, BEIGE, W/O MAG, W1	1.000	

SAITEK

PRODUCT COSTING - SAITEK 30M FORMAT

Run :
Prog :

992990-11EV

- SW19 EV, PRESIDENT CHESS

Rev : 3

Level	Item	Chg	Stock Code	Rev	Qans	Description	Qty Per Reference
5	115		000161-00150	RC		MAGNET, ISO, FERRITE, D13X4	1.000
5	116		295100-08210	RC		FELT, DIA 20MM, BLK, W ADHESIVE	1.000
4			244200-09081	1		CHESSMEN, SW19, QUEEN, BEIGE, D13X4, BLITZ	1.000
5	117		234200-07200	RC		WOOD, QUEEN, BEIGE, W/O MAG, W1	1.000
5	118		000161-00150	RC		MAGNET, ISO, FERRITE, D13X4	1.000
5	119		295100-08210	RC		FELT, DIA 20MM, BLK, W ADHESIVE	1.000
4			244200-09081	1		CHESSMEN, SW19, BISHOP, BEIGE, D13X4, BLITZ	2.000
5	120		234200-07200	RC		WOOD, BISHOP, BEIGE, W/O MAG, W1	1.000
5	121		000161-00150	RC		MAGNET, ISO, FERRITE, D13X4	1.000
5	122		295100-08210	RC		FELT, DIA 20MM, BLK, W ADHESIVE	1.000
4			244200-09081	1		CHESSMEN, SW19, KNIGHT, BEIGE, D13X4, BLITZ	2.000
5	123		234200-07200	RC		WOOD, KNIGHT, BEIGE, W/O MAG, W1	1.000
5	124		000161-00150	RC		MAGNET, ISO, FERRITE, D13X4	1.000
5	125		295100-08210	RC		FELT, DIA 20MM, BLK, W ADHESIVE	1.000
4			244200-09081	1		CHESSMEN, SW19, ROOK, BEIGE, D13X4, BLITZ	2.000
5	126		234200-07200	RC		WOOD, ROOK, BEIGE, W/O MAG, W1	1.000
5	127		000161-00150	RC		MAGNET, ISO, FERRITE, D13X4	1.000
5	128		295100-08210	RC		FELT, DIA 20MM, BLK, W ADHESIVE	1.000
4			244200-09081	1		CHESSMEN, SW19, PAWN, BEIGE, D13X4, BLITZ	8.000
5	129		234200-07200	RC		WOOD, PAWN, BEIGE, W/O MAG, W1	1.000
5	130		000161-00150	RC		MAGNET, ISO, FERRITE, D13X4	1.000
5	131		295100-08210	RC		FELT, DIA 17 MM, BLK, W ADHESIVE	1.000
3	132		243570-19400C			CHESSMEN SET, SW19, ALC	1.000
1			972990-11EV	1		OPTION ASSEMBLY FOR SW19	1.000
2	133		332990-00800	RC		RATING PLATE, FOR SW19	1.000
2	134		412990-61000	RC		MANUAL FOR SW19 E/F/G/D/I/S, SWL	1.000
2	135		422990-61100	RC		GIFTBOX, FOR SW19, E/F/G/D/I/S, SWL	1.000
2	136		430004-51000	RC		CARD, WARRANTY, E/G/F/D/S, SWL, CHESS	1.000
2	137		352990-00701	RC		INLAY, LCD WINDOW, PVC, TRANSPERANT, SLKSC, 6	1.000
2	138		370000-11200	RC		ADDENDUM, COM#112, DISTRIBUTOR LIST, E	1.000
2	139		434016-01004	RC		LEAFLET, CONSUMER, 1993, ENGLISH, SWL	1.000

1.3 Pin Assignments and Functions

1.3.1 Pin Arrangement

Figure 1-2 shows the pin arrangement of the H8/325 Series in the DC-64S and DP-64S packages. Figure 1-3 shows the pin arrangement in the FP-64A package. Figure 1-4 shows the pin arrangement in the CP-68 package.







Figure 1-2. Pin Arrangement (DC-64S, DP-64S, Top View)

8A. FUNCTIONAL TEST PROCEDURE FOR PRESIDENT CHESS (For version 702)

* All following tests must be performed with SW19 chess pieces

<u>Purpose</u>	<u>Procedure</u>	<u>Observation</u>
1. Power up	- Insert six 'C' size batteries into the battery compartment	- Scans LED column by column together with LCD segments displayed in Table 1 - New game sound is emitted - LCD shows 
2. QC test mode	- Press ACL - Press OPTION	- Same as 1 - LCD shows 
	- Press ← twice	- LCD shows 
	- Press ENTER	- All LCD segments are turned ON except PAWN symbol and all a-segment of seven segment digit.

<u>Purpose</u>	<u>Procedure</u>	<u>Observation</u>
	- Press INFO	- LCD shows □ 0 10
3. Reset unit	- Press function keys as shown in Table 2	- See Table 2
4. Chessboard test	- Press ACL	- Same as 1
	- Press POSITION	- LCD show "- POS -"
	- Press CLEAR twice	- LCD show □
	- Press PIECE TYPE twice	- LCD show □ ♔
	- Short the reed switches of row 1 with magnets. After the chessboard LED turns on steadily, put a <u>testing chessman</u> on squares labelled with A on Table 3 (A2, B3, C4....G8, H8)	- Corresponding square LEDs are on and LCD shows the coordinates of the testing chessman
	- Repeat the above step for row 2, 3, 4, 5, 6, 7, 8 and put a testing chessman on squares labelled with B, C, D, E, F, G, H respectively on Table 3.	- Same as above
5. Reset unit	- Press ACL	- Same as 1

<u>Purpose</u>	<u>Procedure</u>	<u>Observation</u>
6. Multimove	- Place all chess pieces on the chessboard	- LCD shows
	- Press OPTION	+ Auto
	- Press ENTER	- LCD shows
	- Press CLEAR	- The clock starts counting
	- Move F2, F4, E7, E5, G2, G4	- Coordinate LEDs come on with a "Beep" for each move and LCD shows corresponding move.
	- Press ENTER	- D8 LED is on and H4 LED is flashing and LCD shows
		D8 - H4
	- Picks up the Black Queen on D8	- H4 LEDs are on and LCD shows as above
	- Put down the Black queen on H4	- LCD shows
		D8 - H4
		and
		AAEE

alternatively, then after a while white clock starts counting up.



<u>Purpose</u>	<u>Procedure</u>	<u>Observation</u>
7. Check memory	- Press GO/STOP - Press OPTION twice - Remove the controller - Plug in the controller - Insert a non-energized adapter - Press GO	- All LEDs and LCD come off - No response - No response - No response - White clocks counting up
8. Check adapter + batteries	- Press GO/STOP - Insert an energized adapter - Press GO	- All LEDs and LCD come off - Same as above - White clocks counting up
9. Check adapter	- Press GO/STOP - Remove batteries - Press GO/STOP - Picks up the Black Queen on H4	- All LEDs and LCD come off - Same as above - White clock counting up - H4 LEDs are on and - LCD shows 
	- Put down the Black Queen on D8	- LCD shows 
	- Press CLEAR	- G4 LED is ON and G2 LED is flashing - Black clocks starts counting up.

Table 1








Sequences	LCD shows	Column LEDs ON
1		A
2		B
3		C
4		D
5		E
6		F
7		G
8		H
9		NIL

Table 2

Function Key Press	LEDs to be ON (for a while)
LEVEL	H2
POSITION	F1
OPTION	H1
INFO	G1
■ / →	B1
□ / ←	A1
ENTER / PLAY	E1
PIECE TYPE	C1
CLEAR	D1
GO / STOP	All LED and LCD OFF

- * A beep sound is given out for each key press.
- * Pressing <ENTER> and <CLEAR> at the same time will exit QC test mode.
- * LCD always shows □ during function key pressed (except in stop mode).

0 10






Table 3

8	G	F	E	D	C	B	A	A
7	F	E	D	C	B	A	H	H
6	E	D	C	B	A	H	G	G
5	D	C	B	A	H	G	F	F
4	C	B	A	H	G	F	E	E
3	B	A	H	G	F	E	D	D
2	A	H	G	F	E	D	C	C
1	H	G	F	E	D	C	B	B
	A	B	C	D	E	F	G	H

Note : The testing chessman should rest on the square for at least 1 second.

8B. FUNCTIONAL TEST PROCEDURE FOR PRESIDENT CHESS
(For version 907 and A08A)

* All following tests must be performed with SW19 chess pieces

<u>Purpose</u>	<u>Procedure</u>	<u>Observation</u>
1. Power up	- Insert six 'C' size batteries into the battery compartment	- Scans LED column by column together with LCD segments displayed in Table 1 - New game sound is emitted - LCD shows 
2. QC test mode	- Press ACL - Press OPTION	- Same as 1 - LCD shows 
	- Press ← twice	- LCD shows 
	- Press ENTER	- LCD shows 
		- Then LCD shows 
		- And LED of square A6 is turned ON steadily.

PurposeProcedureObservation

- Press ENTER

- Scans LED column by column together with LCD segments displayed in Table 1 (except for sequence 9)
- LCD shows

♔

I : V :
I : ^ :

- Press function keys as shown in Table 2
- Short the reed switches of row 1 with magnets. After the chessboard LED turns on steadily, put a testing chessman on squares labelled with A on Table 3 (A2, B3, C4....G8, H8)
- Repeat the above step for row 2, 3, 4, 5, 6, 7, 8 and put a testing chessman on squares labelled with B, C, D, E, F, G, H respectively on Table 3.

- See Table 2
- Corresponding square LEDs are on and
- The coordinates of the square is shown on LCD in the format of

C H 5 : - -

where -- is the coordinates of the testing chessman.

3. Reset unit

- Press ACL

- Same as 1

4. Multimove

- Place all chesspieces on the chessboard
- Press OPTION

- LCD shows

+ A u t o

- Press ENTER

- LCD shows

- A u t o


- Press CLEAR

- The clock starts counting

PurposeProcedureObservation


- Move F2, F4, E7, E5, G2, G4
- Press ENTER

- Coordinate LEDs come on with a "Beep" for each move and LCD shows corresponding move.
- D8 LED is on and H4 LED is flashing and LCD shows




- Picks up the Black Queen on D8
- Put down the Black queen on H4

- H4 LEDs are on and LCD shows as above
- LCD shows



and



alternatively, then after a while white clock starts counting up.

5. Check memory

- Press GO/STOP
- Press OPTION twice
- Remove the controller
- Plug in the controller
- Insert a non-energized adapter
- Press GO

- All LEDs and LCD come off
- No response
- No response
- No response
- White clocks counting up

6. Check adapter + batteries

- Press GO/STOP
- Insert an energized adapter
- Press GO

- All LEDs and LCD come off
- Same as above
- White clocks counting up



<u>Purpose</u>	<u>Procedure</u>	<u>Observation</u>
7. Check adapter	- Press GO/STOP	- All LEDs and LCD come off
	- Remove batteries	- Same as above
	- Press GO/STOP	- White clock counting up
	- Picks up the Black Queen on H4	- H4 LEDs are on and
		- LCD shows
		
	- Put down the Black Queen on D8	- LCD shows
		
	- Press CLEAR	- G4 LED is ON and G2 LED is flashing
		- Black clocks starts counting up.

Table 1









Sequences	LCD shows	Column LEDs ON
1		A
2		B
3		C
4		D
5		E
6		F
7		G
8		H
9		NIL

Table 2

Function Key Press	LED turned ON steadily	LCD display
LEVEL	H2	All segments turned ON
POSITION	F1	
OPTION	H1	
INFO	G1	
 / 	B1	
 / 	A1	
ENTER/PLAY	E1	
PIECE TYPE	C1	
CLEAR	D1	
GO/STOP	All LEDs turned OFF	All LCD segments turned OFF

* A beep sound is given out for each key press.

* Pressing <ENTER> and <CLEAR> at the same time will exit QC test mode.

Table 3

8	G	F	E	D	C	B	A	A
7	F	E	D	C	B	A	H	H
6	E	D	C	B	A	H	G	G
5	D	C	B	A	H	G	F	F
4	C	B	A	H	G	F	E	E
3	B	A	H	G	F	E	D	D
2	A	H	G	F	E	D	C	C
1	H	G	F	E	D	C	B	B
	A	B	C	D	E	F	G	H

Note : The testing chessman should rest on the square for at least 1 second.