

Atlanta



SaitekTM


RT31

PROJECT : RT31 (Atlanta)
DOC. NO. : RT31-PG-010
REV. : 0
DATE : 18-July-97


GENERAL PRODUCT SPECIFICATIONS FOR ATLANTA

- A. Battery requirement : 1.5 Volt (size 'AA' or 'AM-3') x 6 pcs
Alkaline type recommended
- B. Adapter operating : DC 8.0 ~ 13V
voltage range : (recommended to use 9V 300mA center
positive adapter)
- C. Battery operating voltage : 6.6 ~ 10.4 Volts
- D. Current consumption : 10 μ A typical (max. 30 μ A) at STOP mode.
(at battery 9V) : 120mA typical (max. 150mA) at
OPERATING mode.
- E. Power consumption : 1.08W typical (at battery voltage = 9V)
1.35W max
- F. System clock frequency : At V. Batt = 9.0V
20MHz $\pm$ 1% at U1 pin 74
- G. NMI clock frequency : At V. Batt = 9.0V
96KHz $\pm$ 1% of U3 pin 9

PREPARED BY :


Eric Tse

APPROVED BY :


BDM

DIST : BDM, QAM, SED, PE

Filename : /BDD/RT31-PS.Doc

Project : RT31 (ALANTA)
Doc No. : RT31-PS-013
Rev. : 0
Date : 18-Sep-97

ADJUSTMENT PROCEDURE FOR ALANTA


Object : To adjust system clock frequency and NMI clock frequency.

Equipment needed : Frequency counter or CRO capable of frequency measurement up to 20MHz.


System clock : At DC jack = 9.0V
20MHz $\pm 1\%$ at U1 pin 74

- Procedure :
1. Disassemble the unit by removing 3 screws on bottom cabinet and one closed to battery door.
 2. Power on the unit with voltage at DC jack input = 9.0V.
 3. Place probe of counter/scope at pin 74 of U1.
If frequency measured is out of specified range (19.8~20.2MHz), replace C1 or C2 until counter/scope reading is within specification.
 4. Re-assemble the unit.

Prepared by :


Daniel Fong

Approved by :


BDM

Dist : QAM, SED, PE

Filename : /BDD/RT31-PS.Doc


Atlanta Trouble Shooting Chart (RT31)

SYMPTOMS		POSSIBLE CAUSES
Unit cannot be turned ON	1. 2. 3.	Check if MCU_VCC within the range from 4.5V to 5.5V. If it is not within this range, check for : i) Adapter output within 8.0V-13.0V. ii) Broken connections in adapter wiring. iii) Open or shorted circuit in Ground and Vcc traces. iv) Check if ACL switch is shorted to Ground. v) Defective components in power supply circuit (i.e.Q1-Q3,U9) Check for reset signal : Check for U1 pin 79 is logic 'HIGH'. If not, check if C8, R15, D5 are defective. Check for power control signal:. Look for power control output from U1 pin 68 (ie logic high).
No sound	1. 2. 3. 4.	Check for broken wirings from beeper to PCB. Check if beeper is defective. Check if D2, D7 are defective. Check for pulse output from U1 pin 69 when 'SOUND ON'.
LCD missing segment or not turn on	1. 2. 3. 4.	Check for broken or shorted traces on PCB Check for loose contacts or misalignment between LCD and PCB. Check for bad contacts in zebra connector. Check if U7 is defective.
LED missing or turn on when it should not	1. 2. 3. 4.	Check for broken or shorted traces on PCB. Check if LED is defective. Check if R33-R40, U5 and U6 are defective. Check if U1 is defective.
No response or improper response to command keys or chessboard	1. 2. 3. 4. 5. 6. 7.	Check for loose contacts or misalignment between sensors and PCB traces. Check for bad contacts in sensor connectors. Check for broken or shorted traces on PCB or sensor. Check for logic 'HIGH' at U1 pin 60, 88-90 and 92-95 when no key is pressed. Check if R16-R23 are defective. Check if U5 is defective. Check if U1 is defective.

Daniel

No memory function	1. 2.	Check if batteries are dead or weak. Defective U1.
Excessive current drain (use adapter) Current > 150mA when 'ON' Current >20mA when 'MEMORY' or when battery is used: Current > 150mA when 'ON' Current >30uA when 'MEMORY'	1. 2. 3.	Check for component wirings or shorted traces on PCB. Check for contaminations and/or foreign particles on PCB. Check if U1 is defective.
Generates illegal moves	1. 2.	Check if batteries are exhausted. Check if U1 is defective.

Dist : BDM, QAM, PE




SAI TEK - SAI TEKK


see sch
Rev 1.1

0.1 1

3RD	ANGLE	PROJECTION	SIGNATURE	DATE	REV.	ITEM	WAS	IS	DATE	DRAWN	CHECK	BDD	QA	
					DESCRIPTION OF CHANGE				APPROVED					
TOLERANCES			DRAWN BY:	11/12/97	Saitek				TITLE: LOGIC PCB Artwork (Comp SIDE)					
DIM.: ANGLE:			CHECK BY:											
SCALE: 1:1 UNIT: mm			ENGRG AUTH		DWG. NO.: RT31-PE-005				PROJECT: RT31					
QUANTITY:			Q.A. APPD.	11/12/97	P/N.: 514700-00711									
SHEET 2 OF 5			BDD. APPD.	12-12-97	MATERIAL 1.6mm FR4				FINISH Golden Plated					




SAI TEK - SAI TEK



SAI TEK - SAI TEKK




3RD ANGLE PROJECTION			SIGNATURE		DATE	REV.	ITEM	WAS	IS	DATE	DRAWN	CHECK	BDD	QA
TOLERANCES			DRAWN BY: <i>Daniel</i>		11/12/97	0-1-1		See SCH Rev 1.1						
DIM.: ANGLE:			CHECK BY:			DESCRIPTION OF CHANGE		TITLE: <i>ADGK PCB solder mask</i>					(Comp side)	
SCALE: 1:1 UNIT: mm			ENGRG AUTH			DWG. NO.: RT31-PE-005		PROJECT: RT31						
QUANTITY:			Q.A. APPD. <i>[Signature]</i>		15/12	P/N.: 5147.00-0.07.1.0								
SHEET 4 OF 5			BDD. APPD. <i>[Signature]</i>		12.12.97	MATERIAL 1.6mm FR4		FINISH Golden Plated						






SAI TEK - SAI TEKK

3RD	ANGLE	PROJECTION	SIGNATURE	DATE	REV.	ITEM	WAS	IS	DATE	DRAWN	CHECK	BDD	QA
							DESCRIPTION OF CHANGE						
TOLERANCES			DRAWN BY: Daniel	11/12/97			Saitek		TITLE: LOGIC PCB solder mask (solder side)				
DIM.: ANGLE:			CHECK BY:										
SCALE: 1:1 UNIT: mm			ENGRG AUTH				DWG. NO.: RT31-PE-005		PROJECT: RT31				
QUANTITY:			Q.A. APPD.	15.12			P/N: 514700-00710						
SHEET 5 OF 5			BDD . APPD.	12.12.97			MATERIAL 1.6mm FR4		FINISH Golden Plated				

10/32








REVISION

DATE	DESCRIPTION	ECN NO.	REV. NO.
23-9-97	see previous version for the history		
21-11-97	add option 1, C65-66	Te be 15546	1.1
	delete diode D1	ECN97215	

CHESSEBOARD COMMAND KEYS 64 LEDs



COMMAND KEY TABLE

K1	K0
PC7	OPTION
PC6	BLACK/+ POSITION
PC5	CLEAR
PC4	ENTER
PC3	BISHOP
PC2	ROOK
PC1	QUEEN
PA7	KING
PA6	STOP

Saitek Ltd.

SCHEMATIC DIAGRAM

ATLANTA

APPROVALS	DATE
DRAWN: [Signature]	14/1/98
Q.A. [Signature]	21/1/98
B.D.D. [Signature]	14/1/98

MCU NC PINS : 34-39,41,44-47,48,50,71,78

Select either OPTION 1 or OPTION 2 only.

Except U1 and U4, all IC powered by V_{LOG}

DIST: BDM,QAM,SED,PE

DWG. NO. RT31-PE-005

(P.1/3)

REV. 1.1

BILL OF MATERIALS

PROJECT	:	RT31	Atlanta
ART.NO.	:	470	
REVISION	:	1	BDD#/RT31.Doc

REVISION HISTORY

<u>REVISION</u>	<u>DATE</u>	<u>BY</u>	<u>DESCRIPTION OF CHANGES</u>
P1	02.01.97	Leon Wong	Preliminary BOM.
P2	01.05.97	Leon Wong	Change power PCB and components; change connector for LED board to use connector array; logic guts components update.
1	17.10.97	Leon Wong	Update logic guts and power guts for RFI and circuit improvement per ECN97155. Add rubber rod per ECN97145. <i>change to use mark up instead of ETAT.</i>

RELATED DOCUMENTS

Schematic dwg : RT31-PE-005

REV

0.1

Prepared By :

Leon
Leon Wong

Approved by :

30
BDM

Distribution :

+1.00 [X] MMM,FAM,SED; QAM

+0.10 [] MMM,FAM,SED; QAM

Date issue : 21 OCT 1997

994700 - RT31, ATLANTA

Rev : 1

Level	Item	Chg	Stock Code	Rev	Cons Description	Qty	Per Reference
1			984700-00000	1	UNIT ASSEMBLY, FOR RT31	1.000	
2			914700-00001	1	GUTS ASSEMBLY - LOGIC, RT31	1.000	
3	1	*	514700-00711	RC	PCB, LOGIC, D.S., 1.6MM FR4, RT31	1.000	ECN97155
3	2		514700-00710	RC	PCB, LOGIC, D.S., 1.6MM FR4, RT31	.000	RUNNING CHANGE
3	3	*	861623-70704	RC	MICROPROCESSOR, RT31, FP	1.000	ECN97155
3	4		870024-47034	RC	ZTAT, MICROCOMPUTER, HD6477034F20, HITACHI	.000	U1, ALTERNATIVE
3	5		41EPR		EPROM 27C256 PROGRAMMING	.000	ZTAT PROGRAM'G
3	6		741775-04017	RC	TTL, -4017, DECADE COUNTER/DRIVER, HCT	1.000	U5
3	7		750013-04017	RC	IC, DECADE COUNTER/DRIVER, 4017	.000	ALTERNATIVE, U5
3	8		740065-00164	RC	TTL, -164, 8 BIT S/P SHIFT REGISTER, HCT	1.000	U6
3	9		741723-00373	RC	TTL, -373, 8 BIT LATCH, RC, DIP20	1.000	U7
3	10		822060-14260	RC	DRAM, HY514260, 256KX16, 60NS, CMOS, SOJ	1.000	U8
3	11		642000-03130	RC	CRYSTAL, 20MHZ, 30PPM	1.000	X1
3	12		642000-03250	RC	RESONATOR, 20MHZ, 50PPM	.000	X1, ALTERNATIVE
3	13		654148-10000	RC	DIODE, SWITCHING, 1N4148	3.000	D2, D5, D7
3	14		611035-22109	RC	RESISTOR, ARRAY, C-FILM, 10KX8, 5%, 1/8W, 9	1.000	R16-R23
3	15		611035-21102	RC	RESISTOR, FIXED, C-FILM, 10K, 5%, 1/8W	2.000	R48, R53
3	16	NW	612025-31102	RC	RESISTOR, FIXED C-FILM, 2K, 5%, 1/4W	2.000	R55, 56 ECN97155
3	17		613335-21102	RC	RESISTOR, FIXED C-FILM, 33K, 5%, 1/8W	4.000	R9-R12
3	18		611535-21102	RC	RESISTOR, FIXED C-FILM, 15K, 5%, 1/8W	1.000	R15
3	19		614725-21102	RC	RESISTOR, FIXED C-FILM, 4K7 5%, 1/8W	1.000	R32
3	20		615115-21102	RC	RESISTOR, FIXED C-FILM, 510, 5%, 1/8W	8.000	R33-R40
3	21	NW	670290-12GB0	RC	TRANSISTOR, PNP, 9012G, CENTRE B	1.000	Q7, ECN97155
3	22	NW	650000-33915	RC	DIODE, ZENER, 3V9, +/-5%, 1/4W	1.000	Z2, ECN97155
3	23	-1	62200W-05014	RC	CAPACITOR, C-CAP NPO, 20PF, +/-20%, 50V	2.000	C1, C2 ECN97155
3	24		621042-01611	RC	CAPACITOR, C-CAP, 0.1UF, +80-20%, 16V	7.000	C11, C50-C54, C58
3	25		621042-01611	RC	CAPACITOR, C-CAP, 0.1UF, +80-20%, 16V	1.000	C61
3	26		621062-01615	RC	CAPACITOR, E-CAP, 10UF, +80-20%, 16V	1.000	C8
3	27		62227Z-01015	RC	CAPACITOR, E-CAP, 220UF, +80, -20%, 10V	3.000	C57, C59, C60
3	28		630007-20000	RC	INDUCTOR, RFI, 14UH, +/-10%, Q=44MIN	3.000	L3-L5, ECN97155
2			914700-00002	1	GUTS ASSEMBLY - LED, RT31	1.000	
3	29		514490-00320	RC	PCB, LED, SS, 1.6MM, PAPER PHENOLIC, FOR RT8	1.000	
3	30		660001-11003	RC	LED, RED, DOME, D=3MM, TOSHIBA, TLR124	64.000	
3	31		000051-25155	RC	JUMPER, L=12.5MM, LL=15MM, D=0.5MM	44.000	ECN97155
3	32		000030-01060	RC	CONNECTOR ARRAY, N=21, L=150, E=3.5, P=2.54	1.000	2 X 8 PINS
2			914690-00004	1	GUTS ASSEMBLY - KEYBOARD, RT26/RT31	1.000	
3	33		514690-00740	RC	PCB, KEYBOARD, S.S., 1.6MM P.P., RT26/31	1.000	
3	34		000011-00100	RC	ACL, RESET CONTACT, D=10MM, STAINLESS STEEL	17.000	ECN96225
3	35		000030-00900	RC	CONN ARRAY, N=18, L=100MM, P=2.0MM, E=3.5MM	1.000	
3	36		294690-02000	RC	SPACER, 0.3MM PVC WITH D.S. TAPE, RT26	1.000	ECN96225
2			914700-00005	1	GUTS ASSEMBLY - POWER, RT31	1.000	
3	37		000030-01290	RC	CONN ARRAY, N=9, L=210MM, P=2MM, E=3.5MM	1.000	
3	38	*	514700-00951	RC	PCB, POWER, D.S., 1.6MM FR4, RT31	1.000	ECN97155
3	39		514700-00950	RC	PCB, POWER, D.S., 1.6MM FR4, RT31	.000	RUNNING CHANGE
3	40		611025-31102	RC	RESISTOR, FIXED C-FILM, 1K, 5%, 1/4W	2.000	R5, R41
3	41		612025-31102	RC	RESISTOR, FIXED C-FILM, 2K, 5%, 1/4W	2.000	R1, R3
3	42		612025-31102	RC	RESISTOR, FIXED C-FILM, 2K, 5%, 1/4W	.000	OPTIONS: R2, R4

18/32

994700 - RT31, ATLANTA

Rev : 1

Level	Item	Chg	Stock Code	Rev	Cons	Description	Qty	Per Reference
3	43		612035-31102		RC	RESISTOR, FIXED C-FILM, 20K, 5%, 1/4W	1.000	R42
3	44		6110A5-31102		RC	RESISTOR, FIXED C-FILM, 1, 5%, 1/4W	1.000	R43
3	45		612205-31102		RC	RESISTOR, FIXED C-FILM, 22, 5%, 1/4W	1.000	R44
3	46		622272-01015		RC	CAPACITOR, E-CAP, 220UF, +80, -20%, 10V	2.000	C7, C12
3	47		621062-01615		RC	CAPACITOR, E-CAP, 10UF, +80-20%, 16V	2.000	C5, C6
3	48	2	62104W-01611		RC	CAPACITOR, C-CAP, 0.1UF, +/-20%, 16V	5.000	C3, 4, 13, 65, 66
3	49		670285-50DB0		RC	TRANSISTOR, PNP, 8550, D, CENTRE B	2.000	Q1, Q6
3	50		670285-50DB0		RC	TRANSISTOR, PNP, 8550, D, CENTRE B	.000	OPTIONS: Q2
3	51		670180-50CB0		RC	TRANSISTOR, NPN, 8050, C, CENTRE B	1.000	Q3
3	52		690037-RE50A		RC	ELECT, REGULATOR, 5V, 120MA, TO-92, RESRE50AC	1.000	U2
3	53		655817-34015		RC	DIODE, SCHOTTKY, 1N5817, 20 TO 40V, 1A	4.000	D3, D4, D6, D8
3	54		654148-10000		RC	DIODE, SWITCHING, 1N4148	1.000	D1
3	55		690018-7805F		RC	ELECT, REGULATOR, 5V, TO-220F, NJW7805FA	1.000	U9
3	56		630007-20000		RC	INDUCTOR, RFL, 140H, +/-10%, Q=44MIN	2.000	L1, L2
3	57		524690-01110		RC	SWITCH, TACT, RT26, TS-1225-BS	1.000	
3	58		000220-00003		RC	SOCKET, DC POWER JACK, DC 208	1.000	ECN96225
2			964700-00000	1		CASING ASSEMBLY, FOR RT31	1.000	
3	59		314690-00400		RC	SENSOR, CHESSBOARD, COMBO, RT26/31	1.000	
3	60		324490-00610		RC	OVERLAY, FOR RT31, CHESSBOARD, COMBO, LEXAN	1.000	
3	61		224490-00700		RC	METAL PLATE, 213.3X202.2MM, W/D TAPE, HOLES	1.000	
3	62		354470-01900		RC	INLAY, FOR T. COVER, METAL W/PVC, BLK, RT6/8	2.000	
3	63		344700-00200		RC	NAME PLATE, PVC, ATLANTA, SILKSCREEN, RT31	1.000	
3	64		354690-00800		RC	INLAY, FOR JACK, PVC, BLACK, RT26/31	1.000	
3	65		224470-02500		RC	METAL, B-CONT, '-' , BRONZE, NI-PLT, RT6	1.000	
3	66		224470-02600		RC	METAL, B-CONT, '+' , BRONZE, NI-PLT, RT6	1.000	
3	67		224470-02700		RC	METAL, B-CONT, '+' , BRONZE, NI-PLT, RT6	2.000	
3	68		532820-00290		RC	LCD, FOR ST12	1.000	
3	69		000090-00320		RC	FOAM PAD, 52X25X6MM	1.000	
3	70		250000-00525		RC	ZEBRA CONNECTOR, SG, 51.4X2.4X8.2MM	1.000	
3	71		215120-02503		RC	PLASTIC, SENSOR CLAMP, LARGE, PC, CLEAR	1.000	ECN96284
3	72		214210-03500		RC	PLASTIC, LOCK PIN, NYLON 66, WHITE	1.000	
3	73	NW	250000-00150		RC	RUBBER ROD, 48X2.9X2.8MM, COMPRESS KE951U	1.000	ECN97145
3	74		000130-00270		RC	BUZZER, D=27MM	1.000	
3	75		000073-11434		RC	SCREW, S/T, +BIND, M2.6X8MM, A	7.000	KEY PCB MOUNT
3	76		000073-11434		RC	SCREW, S/T, +BIND, M2.6X8MM, A	8.000	LOGIC PCB MOUNT
3	77		000073-11434		RC	SCREW, S/T, +BIND, M2.6X8MM, A	2.000	POWER PCB MOUNT
3	78		000073-11434		RC	SCREW, S/T, +BIND, M2.6X8MM, A	11.000	LED PCB MOUNT
3	79		000073-41434		RC	SCREW, S/T, +CSR, HD, M2.6X8MM, A	3.000	BOTTOM CABINET
3	80		000073-12434		RC	SCREW, S/T, +BIND, M2.6X8MM, BT	1.000	BATT. COMPART'M
3	81		000021-00140		RC	RUBBER FT, 3W/MIG. FREE, D30.5X1.6MM, ADHE.	4.000	
3	82		000062-10043		RC	STRAND WIRE, RED, L=100MM, E=3.5MM, AWG28	1.000	B+
3	83		000060-21043		RC	STRAND WIRE AWG28, E=3.5MM, L=210MM, BLACK	1.000	B-
3	84		000061-10043		RC	STRAND WIRE, BROWN, L=100MM, E=3.5MM, AWG28	2.000	BUZZER
3			954700-00000	1		CABINET SET, FOR RT31	1.000	
4	85		214690-00310		RC	PLASTIC, TOP COVER, HIPS, SPRAY BLACK	1.000	
4	86		214470-01600		RC	PLASTIC, INNER PLATE, HIPS, BLACK	1.000	
4	87		214690-00200		RC	PLASTIC, T. CAB, HIPS, SPY. BLACK, SILKSCREEN	1.000	
4	88		214690-00300		RC	PLASTIC, BOTTOM CABINET, HIPS, BLACK	1.000	
4	89		214470-00740		RC	PLASTIC, BATT. DOOR, HIPS, SPY. BLACK, S. SCR N	1.000	

19/32

994700 - RT31, ATLANTA

Rev : 1

Level	Item	Chg	Stock Code	Rev	Cons	Description	Qty	Per Reference
4	90		214470-00800		RC	PLASTIC,KNOB KEY,ABS,BLACK	17.000	
1			944700-10000	1		PACKING ASSEMBLY,FOR RT31	1.000	
2	91		454490-01000		RC	INSERT,FOR RT5/6/8,MAIN BODY,CORR.PAPER	1.000	
2	92		454490-01010		RC	INSERT,FOR RT5/6/8,TOP COVER,CORR.PAPER	1.000	
2	93		494470-02400		RC	REMARK SHEET,FOR RT6/RT8	15.000	
2	94		360000-00240		RC	LABEL,FOR SERIAL NO,ADHESIVE PAPER H+G	1.000	
2	95		000124-50310		RC	POLYBAG,450X310X0.045MM	1.000	FOR UNIT
2	96		462910-10600		RC	ACCESSORY,POUCH,FOR SA9 CHESSMEN	1.000	
2	97		454700-00400		RC	CARTON,FOR RT31,5PCS/CTN	.200	
2			244690-30800	1		CHESSMEN SET,RT26/31,199+203	1.000	
3	98		262050-00151		RC	CHESSMEN,YOIC,16,GLOSSY BLACK,ROB MAG	1.000	
3	99		262050-10151		RC	CHESSMEN,YOIC,16,GLOSSY BLACK,ROB MAG	.000	ALTERNATIVE
3	100		262050-00111		RC	CHESSMEN,YOIC,16,LIGHT GREY,ROB MAGNET	1.000	
3	101		262050-10111		RC	CHESSMEN,YOIC,16,LIGHT GREY,ROB MAGNET	.000	ALTERNATIVE
1			974700-00000	1		OPTIONS ASSEMBLY,FOR RT31	1.000	
2	102		334700-00300		RC	RATING PLATE,FOR RT31,PVC,H&G	1.000	
2	103		424700-61100		RC	GIFTBOX,FOR RT31,E/G/F/D/S/I,SWL	1.000	
2	104		414700-02100		RC	MANUAL,FOR RT31,GERMAN,H&G	1.000	
2	105		414700-53200		RC	MANUAL,FOR RT31,E/D/F/S/I,H&G	.000	
2			490000-00000	1		CONSUMER LEAFLET LISTING ASSEMBLY	1.000	
3	106		430016-01006		RC	LEAFLET,CONSUMER,1995,ENGLISH,SWL	1.000	ENG. COUNTRIES
3	107		430017-02007		RC	LEAFLET,CONSUMER,1995,GERMAN,SWL	.000	GERMAN
3	108		430021-01004		RC	LEAFLET,CONSUMER,1994,ENGLISH,DIXONS	.000	DIXONS
2			490000-00010	1		WARRANTY CARD LISTING ASSEMBLY	1.000	
3	109		430004-51000		RC	CARD,WARRANTY,E/G/F/D/S,SWL,CHESS	1.000	CHESS PRODUCT
3	110		430008-51000		RC	CARD,WARRANTY,E/G/F/D/S,SWL,NON CHESS	.000	NON-CHESS
3	111		430064-02000		RC	CARD,GUARANTEE,SCHNEIDER,G	.000	SCHNEIDER
3	112		430048-01003		RC	CARD,GUARANTEE,E,CONTEMPORARY GAMES	.000	CCC
3	113		430113-02001		RC	CARD,GUARANTEE,GERMAN,H&G	.000	GERMAN & ADST.
3	114		370000-09200		RC	CARD,COW#92,GUARANTEE,TRANSECOM	.000	TRANSECOM
3	115		430120-01000		RC	CARD,WARRANTY,ENGLISH,SCI	.000	SCI
3	116		430162-02000		RC	CARD,GUARANTEE CARD,FOR H+G,PCP,GERMAN	.000	
3	117		430165-01000		RC	CARD,GUARANTEE,FOR SP,PCP,ENGLISH	.000	
2			490000-00020	1		RULE OF CHESS LISTING ASSEMBLY	1.000	
3	118		430156-01000		RC	BOOK,RULES OF CHESS,ENGLISH,SWL	1.000	
3	119		430157-03000		RC	BOOK,RULES OF CHESS,FRENCH,SWL	.000	
3	120		430158-46000		RC	BOOK,RULES OF CHESS,G/D/I/S,SWL	.000	
2			370000-00000	1		LABEL ASSEMBLY	1.000	
3	121		370000-00104		RC	LABEL,COW#1,FOR SWL,ENGLISH,CE LABEL	.000	ECN-96049
3	122		370000-00103		RC	LABEL,COW#1,FOR SWL,ENGLISH,CE LABEL	.000	RUNNING CHANGE
3	123		370000-19801		RC	LABEL,FOR ALL PRODUCTS EXC.PCP TO FRANCE	.000	ECN-97122
3	124		370000-19800		RC	LABEL,COW#198,MADE IN CHINA,TRANSECOM	.000	ECN97122,USE-UP
3	125		370000-18200		RC	LABEL,MADE&PRINTED IN CHINA,ADHESIVE	.000	ECN 96235
3	126		370000-20100		RC	STICKER,COW#201,"AGES 8 AND UP"	.000	

20/32

SAITEK LTD.

REPORTS BILL OF MATERIAL - SAITEK

Run : 17/10/97 15:33 Page 4

Prog: KPSPC/6B03

994700


- RT31, ATLANTA

Rev : 1

Level	Item	Chg	Stock Code	Rev	Cons	Description	Qty Per Reference
3	127		370000-01001	RC		LABEL, COM#10, FOR OTTO GIFTBOX	.000 OTTO
3	128		370000-01100	RC		LABEL, COMMON, NO:11, FOR PLATETIME BOX	.000 PLATETIME
3	129		370000-01200	RC		LABEL, COMMON, NO:12, FOR SEARS, CAN	.000 SEARS
3	130		370000-01300	RC		LABEL, COMMON, NO:13, DICK SMITH ON BOX	.000 DICK SMITH
3	131		370000-07600	RC		STICKER, COM#78, GREEN POINT, GERMAN, 20MM	.000 GERMAN
3	132		370000-08600	RC		ADDENDUM, COM#86, FOR ALL, RECYCLE, QUELLE	.000 QUELLE
3	133		430063-01000	RC		ADDENDUM, E, FOR SOKL SHIPMENT, HELP LINE	.000 SYSTEMA
3	134		370000-11204	RC		ADDENDUM, DISTRIBUTORS LIST 97, ENGLISH	.000 ECN97066
3	135		370000-14100	RC		STICKER, COM#141, FOR L'WOODS CARTON, PAPER	.000 L'WOODS QTY=3
3	136		370000-17500	RC		STICKER, COM#175, TOY SYMBOL	.000 FOR NO TOY SYMB
3	137		370000-04900	RC		STICKER, COM#49, GREEN POINT, GERMAN LARGE	.000
3	138		430026-01004	RC		CARD, ACCESSORY ORDER, E, SCI	.000 SCI, CHESS ONLY
3	139		430100-61000	RC		ADDENDUM, ADAPTOR WARNING, E/G/F/D/S/I	.000 ECN 95199
3	140		370000-15900	RC		ADDENDUM, COM#159, TOY SYMBOL, H+G	.000 ECN 95201
3	141		370000-20200	RC		STICKER, COM#202, USCF, FOR CHESS TO SCI	.000
3	142		430123-01000	RC		CARD, USCF, FOR CHESS PRODUCTS TO SCI, E	.000
3	143		370000-20400	RC		STICKER, H&G HOTLINE ON BACK OF UNIT	.000 GERMAN
3	144		430124-02000	RC		ADDENDUM, INFO FOR CHESS, GERMAN, H&G	.000 GERMAN (CHESS)
3	145		370000-21000	RC		STICKER, COM#210, RECYCLE PAPER, 3 SUISES	.000 ECN-96109
3	146		370000-21100	RC		STICKER, COM#211, ADDRESS LABEL, FOR SEARS	.000 ECN-96161
3	147		370000-21800	RC		ADDENDUM, COM#218, BAT. WARNING, E/F/G/D/S/I	.000 ECN-97119


21/32

u1




Note: V_{CC}: SH7032, SH7034 (Masked ROM version) V_{PP}: SH7034 (PROM version)

(TOP VIEW)




u4

(TOP VIEW)




u5

(TOP VIEW)




u6

(TOP VIEW)



u7

u8



8. **FUNCTIONAL TEST PROCEDURE FOR RT31**

Insert six AA size batteries into the battery compartment.


<u>Purpose</u>	<u>Procedure</u>	<u>Observation</u>
1. QC test mode	- Press ACL - Press  and  simultaneously while LED/LCD scanning	- A single beep sound is emitted - LCD and LED scanning as Table 1 - H8 LED is on and LCD displays The image shows a rectangular LCD display. On the left, there are two vertical bars of dots. In the center, there are two sets of dots arranged in a cross pattern. On the right, there is a small icon of a king chess piece.
2. Function keys and chessboard square test	- Press function key as Table 2 - Press 64 chessboard square	- See Table 2 - LCD displays The image shows a rectangular LCD display with the text "CH5:--" in a large, blocky font. ("—" = corresponding square coordinate) and corresponding square LED are turned on steadily with beep sound
3. Reset	- Press ACL	- LCD and LED scanning as Table 1 (1-8) and then LCD displays: The image shows a rectangular LCD display with the text "0:00:00" in a large, blocky font. Above the first zero, there is a small square icon. Note: The unit is defective if LCD displays "Err 0", "Err A" or "Err E" during power up

PurposeProcedureObservation

4. Multimove


- Press **TAKEBACK** key

- LCD shows


- Press square **F2**, **F4**, **E7**, **E5**, **G2**, **G4** in sequences

- Corresponding coordinate LED (F2, E7 or G2) turn on with a beep sound for each keypress and LCD shows the corresponding move

- Then LCD shows

- Press **CLEAR**, then **ENTER**


- D8 LED are on and LCD shows

- Press **D8**


- H4 LED are on and LCD shows as above

- Press **H4**

- LCD shows



and



alternately (for about 16 seconds), then white clock is displayed

<u>Purpose</u>	<u>Procedure</u>	<u>Observation</u>
5. Auto power off test	- Press OPTION, WHITE/- then ENTER, CLEAR	- Clock counts up and after about 50 sec., "+apd" is flashing on LCD for about 10 sec. then unit is turned off
	- Press GO	- White clock is displayed on LCD
	- Press OPTION WHITE/- then ENTER, CLEAR	- Same as above
6. Check adapter batteries	- Press STOP	- LCD turns off
	- Insert non-energized adapter into DC jack	
	- Press GO	- Same as before STOP key is pressed
	- Press STOP	- LCD turns off
	- Replace the non-energized adapter with energized adapter (9V 300mA center positive)	
	- Press GO	- Same as before STOP key is pressed.
7. Check adapter input	- Press STOP	- LCD turns off
	- Remove the batteries from the compartment	
	- Press GO	- Same as before STOP key is pressed

















<u>Purpose</u>	<u>Procedure</u>	<u>Observation</u>
8. Check high/low voltage	- Press STOP	- LCD is turned off
	- Insert a battery tester to battery compartment with output voltage of the tester sets to 10.4V	
	- Remove the 9V adapter from the unit	
	- Press GO	- LCD displays same as before STOP key is pressed
	- Press STOP	- LCD is turned off
	- Set the output voltage of the tester to 6.6V	
9. Check memory	- Press GO	- LCD display same as before STOP key is pressed
	- Press TAKEBACK then WHITE / -	- LCD shows
		 with H4 LEDs and "d8-H4" are flashing
	- Press H4	- LCD same as above without flashing and D8 LEDs are ON
	- Press D8	- LCD shows
		
10. Test Finished	- Remove the battery tester from the unit	- All LEDs and LCD are off

Table 1

Sequence	LCD shows		Row / LED to be ON
1			A1 - A8
2			B1 - B8
3			C1 - C8
4			D1 - D8
5			E1 - E8
6			F1 - F8
7			G1 - G8

Sequence	LCD shows		Row / LED to be ON
8			H1 - H8
9			H8
10			A1 - A8
11			B1 - B8
12			C1 - C8
13			D1 - D8
14			E1 - E8

20/32

Sequence	LCD shows		Row / LED to be ON
15			F1 - F8
16			G1 - G8
17			H1 - H8

Note : the unit is defective if LCD displays "Err 0" or "Err A" or "Err E" during power up.

Table 2

Function key pressed	LED on
LEVEL	E1
	H2
	G2
	F2
	E2
	D2
	C2
POSITION	F1
OPTION	D1
INFO	G1
TAKEBACK	A1
BLACK / +	B2
WHITE / -	A2
CLEAR	C1
ENTER	B1

* LCD is blank in function key test.

* A beep sound is emitted for each function key press.