



SaitekTM

RD2

PROJECT : Mephisto LCD Modul 6. Generation (RD2)
DOC. NO. : RD2-PG-009
REV. : 0
DATE : 20 August, 1996

GENERAL PRODUCT SPECIFICATIONS FOR MEPHISTO
LCD MODUL 6. GENERATION

- A. Operating voltage : 4.5 - 5.5 volts
- B. Current consumption : Operating voltage = 5V
4 μ A Typical
30 μ A max
- C. Power consumption : 150 μ W max

PREPARED BY :

K. H. AU

APPROVED BY :


DIST : BDM, QAM, SED, PE

Filename : RD2_PS.DOC

ORIGINAL

REVISION

DATE	DESCRIPTION	ECN REV. NO.	REV. NO.



APPROVALS	DATE	Saitek Ltd.
DRAWN <i>LF</i>	28/11/96	
Q.A. <i>LF</i>	28/11/96	
B.D.D. <i>LF</i>	28/11/96	
TITLE: LCD MODULE 6. GENERATION		
DWG. NO. 473		
RD2 - PE - 010		REV. 0

Dat: BDM, QAM, SED, IE

Project : LCD Module 6. Generation (RD2)
 Doc. No. : RD2-PS-011
 Rev. : 0
 Date : 11 December, 1996

Trouble Shooting Chart For LCD Module 6. Generation





SYMPTOMS		POSSIBLE CAUSES
LCD malfunction or unit does not function	1. 2. 3. 4. 5. 6. 7. 8.	Use known working Logic module and the Exclusive board for tests. Check if Vcc is 4.5 V to 5.5 V. Check if the 40-pin connector is bad contact or contaminated. Check for broken wires between PCBs. Check for short/open circuit on PCBs. Check if LCD defective or misaligned. Check for dust or oxide on gold fingers of PCB. Check if there are square waves at pin2-5 and pin10-13 of U1, U2 and U3.
Excessive current drain Current > 30 μ A	1. 2. 3.	Check for short circuit on PCB. Check if the voltage level of a logic 'HIGH' at pin2-5 and pin10-13 of U1, U2 and U3 are within 4.5 V to 5.5 V. Check for leakage on C1 to C4.

Dist : BDM, QAM, SED, PE

Handwritten signature/initials


SIGNATURE	DATE	REV.	ITEM	WAS	IS	DATE	DRAWN	CHECK	BDD	QA	APPROVED

3RD	ANGLE	PROJECTION	SIGNATURE	DATE	REV.	ITEM	WAS	IS	DATE	DRAWN	CHECK	BDD	QA
TOLERANCES			DRAWN BY: K. H. LEE	27/12/19				DESCRIPTION OF CHANGE					
DIM:			CHECK BY: ALR	28/12/19				TITLE: RD2 LCD PCB SILKSCREEN					
SCALE: 2:1			ENGR GAUTH					DWG. NO.: RD2-PE-006SS					
UNIT: MM			Q.A. APPD.	29.12				P/N: N11A7301-006210					
QUANTITY:			BDD APPD.	28/12/19				MATERIAL Paper Phenolic					
SHEET 1 OF 4									FINISH Flash Gold Plating				
									PROJECT: RD2				





3RD	ANGLE	PROJECTION	SIGNATURE	DATE	REV. ITEM	WAS	IS	DATE	DRAWN	CHECK	BDD	QA
TOLERANCES	ANGLE		DRAWN BY: K.H. LEE	27/12/95	DESCRIPTION OF CHANGE							
Q.M.			CHECK BY: R.R.	27/12/95								
SCALE: 2:1	UNIT: MM		ENG'G AUTH		SAITEK							
QUANTITY:			Q.A. APPD.		DWG. NO.: RD2-PE-04535							
SHEET	1	OF 4	BDD. APPD.		PIN: 15, 1, 4, 7, 3, 0, 1, 0, 0, 5, 1, 1, 0							
					MATERIAL: 1.6mm PAPER PHTHALIC							
					FINISH: Bare Copper							
					PROJECT: RD2							

5-1







Saitek
LCD MODUL 6.GENERATION



REDUCED TO 78.0 MM


3RD ANGLE PROJECTION	SIGNATURE		DATE	REV. IT	WAS	IS	DATE DRAWN	CHECK	BDD	OA
TOLERANCES	DRAWN BY:	K. H. LEE	27/12/94	DESCRIPTION OF CHANGE		TITLE: RD2 LOGIC PCB		BDD APPROVED		
DIM.: ANGLE:	CHECK BY:	MLR	27/12/94	DWG NO.: RD2-PE-002CS		PROJECT: RD2				
SCALE: 2:1 UNIT: MM	ENGRG AUTH			PIN: 1,1,4,7,3,0,1-0,0,5,1,10		FINISH: Bare Copper				
QUANTITY:	O.A. APPD.			MATERIAL: 1.6mm PAPER PHEONLIC						
SHEET 2 OF 4	BDD APPD.									

E-TEST REQUIREMENT	YES	NO
		✓



ORIGINAL

REVISION		ECN REV. NO.	
DATE	DESCRIPTION	NO.	NO.



APPROVALS		DATE	
DRAWN		28/11/96	
CHECKED		29/11/96	

U1 - U3 : CD4015B

Saitek Ltd.

SCHEMATIC DIAGRAM

SAITEK

BILL OF MATERIALS

PROJECT : RD2 (Mephisto LCD Module)
ART.NO. : 473
SHIP VER. : EV
REVISION : 1

REVISION HISTORY

<u>REVISION</u>	<u>DATE</u>	<u>BY</u>	<u>DESCRIPTION OF CHANGES</u>
1	3/4/96	K.H. AU	First BOM.

RELATED DOCUMENTS REV

Schematic dwg : RD2-PE-003 0

Prepared By :

Abraham Au
Abraham Au

Approved by :

BDM
BDM

Distribution :

+1.00 [X] MMM, FAM, SE, QAM
+0.10 [] MMM, FAM, SE, QAM
+0.01 [] MMM, IEM


Date issue : 6 APR 1996

994730 - RD2, MEPHJSTO LCD MODUL


Rev : 1

Level	Item Chg	Stock Code	Rev	Cons	Description	Qty Per Reference
1		984730-00000	1		UNIT ASSEMBLY, FOR RD2	1.000
2		914730-00001	1		GUTS ASSEMBLY, -LOGIC, FOR RD2	1.000
3	1	514730-00510			PCE, LOGIC, S.S., 1.6MM, PAPER, PHEONLIC, RD2	1.000
3	2	750008-04015	RC		IC, DUAL 4-BIT SHIFT REGISTER,	3.000 U1-U3
3	3	621040-01611			CAPACITOR, C-CAP, 0.1UF, +/-20%, 16V	3.000 C1-3
3	4	621067-0161X			CAPACITOR, E-CAP, 10UF, +80%/-20%, 16V, MINI	1.000 C4
3	5	000190-00027			CONNECTOR, EDGE, 40PIN, BENDED LEADS	1.000 CON1
2		914730-00003	1		GUTS ASSEMBLY, -LCD, FOR RD2	1.000
3	6	514730-00620			PCE, LCD, S.S., 1.6MM, PAPER, PHEONLIC, RD2	1.000
3	7	000030-01400			CONN ARRAY, N=11, L=40MM, P=2.54MM, F=3.5MM	3.000
2		964730-00000	1		CASING ASSEMBLY, FOR RD2	1.000
3		954730-00000	1		CABINET SET, FOR RD2	1.000
4	8	214610-00120	RC		PLASTIC, T.CAB, ABS, BLACK, W/STLKSCREEN, RD2	1.000
4	9	214610-00200	RC		PLASTIC, B.CABINET, ABS, BLACK, RM1A	1.000
3	10	53208B-00390	RC		LCD, FOR ST12B	1.000
3	11	250000-00524	RC		ZERRA CONNECTOR, SG, 52X2, 2X4, 7, P=0.18MM	1.000
3	12	212080-01100	RC		PLASTIC, SUPPORT FRAME, HIPS	1.000
3	13	000073-11424			SCREW, S/T, +BIND, M2, 6X6MM, A	4.000
1		944730-10000	1		PACKING ASSEMBLY, FOR RD2	1.000
2	14	000122-40130			POLYBAG, 240X130X0.045MM	1.000
2	15	424730-61100	RC		GIFIEDX, FOR RD2, G/E/E/D/I/S	1.000
2	16	454660-00700			INSERT, FOR RM20, CORRUGATED PAPER	1.000
2	17	360000-00220			LABEL, FOR SERIAL NO, ADHESIVE PAPER, STD.	1.000
2	18	454660-00800			CARTON, FOR RM20, 20PCS/CTN	.050
2	19	370000-00000			LABEL ASSEMBLY	1.000

CONNECTION DIAGRAM



FUNCTIONAL DIAGRAM



RECOMMENDED OPERATING CONDITIONS

V_{DD}	Supply voltage: HCC types HCF types	3 to 18 3 to 15	V V
V_I	Input voltage	0 to V_{DD}	V
T_{op}	Operating temperature: HCC types HCF types	-55 to 125 -40 to 85	°C °C

9. FUNCTIONAL TEST PROCEDURE FOR RM19 WITH RD2

Make sure that the ON/OFF switch of RW9 is at OFF position before any module is inserted into the unit, then insert the MMVI Module (RM19 logic unit) and LCD Module (RD2-Mephisto 6. GENERATION LCD MODUL) into the slots. Hence insert the energized adapter into DC socket.

Purpose

Procedure

Observation


1. QC mode
(make sure that no chesspiece is located on the chessboard)

- Slide the ON/OFF switch to ON position while pressing  and  key at the same time for 2 seconds.

- LCD and LEDs scanning (see Table 3)


- Press  key

- LCD and LEDs scanning as Table 3 without sequence 9, 10.
- LCD shows



- Place a RW9 chesspieces on square A1 to H8 sequentially
(make sure to remove all chesspiece before testing the function keys on next step)

- Corresponding square LED is on and LCD shows



- Press function keys as shows in Table 4

- where -- is the coordinate of the square
- See Table 4

PurposeProcedureObservation

2. Newgame and set options

- Press **NEWGAME**


- LCD and LED scanning, see Table 3 without step 9 and 10 (If "Err: E" is shown on LCD, refer to section 7.3)

- Setup pieces at Newgame position

- Newgame sound


- Press **OPT**

- LCD shows




- Press **ENT**

- LCD shows




- Press **■/→** (if "-Snd" is displayed instead, then press **ENT** once to modify the display)

- LCD shows




- Press **■/→** (if "+SiL" is displayed instead, then press **ENT** once to modify the display)

- LCD shows



- Press **■/→** twice (if "+tic" is displayed instead, then press **ENT** once to modify the display)


- LCD shows



PurposeProcedureObservation


- Press  (if "+c:dn" is displayed instead, then press ENT once to modify the display)

- LCD shows



- Press CL

- LCD shows




3. Multimove

- Move F2, F4, E7, E5, G2, G4 in sequence

- Coordinate LEDs come on with a "Beep" for each key press and LCD shows corresponding move.

- Press ENT

- D8 LED and H4 LED are flashing alternatively and LCD shows



- Pick up the piece on square D8


- H4 LED is on and LCD shows as above

PurposeProcedureObservation


5. Check memory

- Place the piece on square H4

- LCD shows



and



alternatively


(after a while white clock is counting up)

- Press CL

- white clock counting up

- Press SAVE

- LCD displays



for a while, then return to previous clock (stopped) with one of the chess piece symbol is displayed on LCD

- Slide the ON/OFF switch to OFF position

- All LEDs come off

- Press NEWGAME twice
- Slide the ON/OFF switch to ON position


- LCD blank
- No response
- LCD and LEDs scanning as Table 3 (without step 9, 10)

- Pick up the Black Queen on H4

- LCD display as before without the chess piece symbol

- H4 LEDs are on and


- LCD shows



PurposeProcedureObservation


- Put down the Black Queen on D8

- LCD shows




- Press CL
- Press NEWGAME

- G4 and G2 LEDs are flashing alternatively
- Black clock starts counting up
- New game sound is emitted
- LCD shows




- Press SAVE

- LCD displays




for a while then LCD shows



6. Power off

- Slide the ON/OFF switch to OFF position
- Slide the ON/OFF switch to ON position

- All LEDs come off
- LCD blanks
- LCD and LED scanning as Table 3 (without step 9 and 10)
- LCD then shows



(If "Err:E" is displayed, the EEPROM or unit is defective)

Table 3





Sequence	LCD shows	Row /LED to be ON
1		Row 1
2		Row 2
3		Row 3
4		Row 4
5		Row 5
6		Row 6
7		Row 7
8		Row 8
9		None
10		Square A6

Table 4

Function Key Press	LCD displays	Function Key Press	LCD displays
	11	LEV	6
	12	INFO	5
	13	POS	8
	14	□ / ←	2
	15	■ / →	1
	16	ENT	10
SAVE	4	CL	9
OPT	7		

- * A beep sound is given out for each key press.
- * Pressing <NEWGAME> will exit QC test mode.